



WAHSA TGN06 Revision 2 Technical Guidance Note 6 (formerly TGN10)

GUIDANCE ON THE USE AND INSPECTION OF MOBILE MAN ANCHORS TO BS EN 795 CLASS E

A series of informative notes for all industries involved with work at height or rescue.



WAHSA TGN06 Technical Guidance Note 06 (formerly TGN10)

GUIDANCE ON THE USE AND INSPECTION OF MOBILE MAN ANCHORS TO BS EN 795 CLASS E

INTRODUCTION

This leaflet is designed to give guidance on deadweight anchors certified to BS EN 795 Class E: 2012 and in accordance with the recommendations of BS 7883: 2005.

It offers general advice about the types of issues surrounding the selection and use of the deadweight anchors and offers guidance on preferable methods of use.

The information contained in this material has been compiled by the Working at Height Safety Association from information that is already in the public domain. The material is intended to provide guidance but does not interpret and apply the law to particular circumstances and cannot be relied upon as advice.

To the fullest extent permitted by law, neither the Working at Height Safety Association nor its employees, officers or members will be liable by reason of breach of contract, negligence or otherwise from any loss or damage (whether direct, indirect or consequential) occasioned to any person acting or omitting to act or refraining from acting upon this material. Such loss and damage as referred to above shall be deemed to include, but is not limited to, any loss of profits, anticipated profits, damage to reputation or goodwill, loss of business or anticipated business, damages, costs, expenses incurred or payable to any third party (whether direct, indirect or consequential), or any other direct, indirect or consequential loss or damage.

All advice or information contained in publications by Work at Height Safety Association (WAHSA) is intended for users who will evaluate the significance of the advice or information, including its limitations, and take responsibility for its use and application.



1 WHAT ARE DEADWEIGHT ANCHORS?

Deadweight anchors provide a secure anchorage point for use on horizontal surfaces (usually with an incline angle less than 5°) where the installation of a permanent anchor point may be unsuitable. A number of different designs are available which incorporate either concrete/steel weights or water to provide an anchor point for fall arrest or work restraint. The anchor point relies on mass and friction between itself and the surface to provide suitable anchorage.

The deadweight anchors are relatively quick and easy to install and can be removed after the work is completed leaving no trace.

Deadweight anchors are certified under BS EN 795 and are designed so that they are of sufficient strength to sustain the maximum dynamic force generated by a fall from height of one person. However, the static strength tests are designed with a minimum factor of safety of two to allow for misuse in real world applications.

All anchor points must be tested even if they are to be used for restraint only.

2 WHEN SHOULD DEADWEIGHT ANCHORS BE USED?

A deadweight anchor should be used when it is not possible to provide a fixed anchor point such as a bolted or chemical anchor. They are of particular benefit on flat roofs such as bitumen, PVC or EPDM where perforation of the surface is undesirable and often costly.

Due to fact that the deadweight anchors are temporary installations makes them ideal for occasional access or inspection work. They can also be moved to different positions and locations relatively easily.

Deadweight anchors can be also be used in environments absent of installed safety components such as guardrails or permanent lifelines systems.

3 SAFETY ISSUES

Several safety issues have been raised with respect to these products. These include, but are not limited to:

- Deadweight anchors should be used in accordance with the manufacturer's instructions and information and should be certified in accordance with BS EN 795 Class E
- Every effort should be made to ensure that all users are familiar with the instructions for use and should be familiar with the instructions for any other PPE that is used in conjunction with the deadweight anchor
- Sufficient care should be taken to ensure that unauthorized use is controlled. This may include additional signage on site. All equipment that is intended for use as PPE should be clearly marked using a diagram as well as sufficient text
- It is essential that a method statement and risk assessment is conducted before each and every use of a deadweight anchor. This is likely to include the height of the building or structure and considerations for which types of PPE will be used in conjunction with the deadweight anchor
- Deadweight anchors containing water should be removed from service if any leakage is found
- Deadweight anchors should only be used on surface types as tested and specified within the manufacturer's instructions and information



4 USING DEADWEIGHT ANCHORS

When using deadweight anchors, it is recommended that users work in restraint rather than fall arrest where possible. This reduces the risk of a user falling over an edge. For example, a rope and rope grab would be preferable to an inertia fall arrest block. The rope grab should be taught to prevent a user entering a fall arrest situation as far is reasonably practicable.

Manufacturers often set a minimum safe distance that the anchor must be placed away from an exposed edge (usually 2.5m) and specify a minimum ground clearance (such as 4m). These distances may be affected by the choice of PPE used in conjunction with the deadweight anchor.

Note: see WAHSA PGN 01 **"10 points for the use of fall protection equipment"** for further guidance on essential considerations when using this equipment.

5 INSPECTIONS AND CHECKS

Deadweight anchors should be inspected by the user before each and every use (pre use inspection) and on a regular basis by a competent person (detailed inspection). An interim inspection may also be required depending on working conditions. Deadweight anchors must be supplied by the manufacturer with a declaration of conformity to BS EN 795: 2012 and manufacturer's instructions and information.

For general information about inspecting fall protection equipment see WAHSA PGN02. This indicates several types of inspection, such as pre-use checks (carried out by the user), detailed inspection (sometimes referred to as 'periodic examination') and, where required, interim inspection (see also INDG367 – HSE).

5.1 PRE-USE CHECKS

The pre use checks should include a visual inspection of all the components of the deadweight anchor. Proof load tests should **not** be carried out. There are a number of factors that may affect the structural integrity of the deadweight anchor. These may include but are not limited to, general wear and tear, impacts, exposure to the elements, dropping or chemical contamination.

As with all PPE, it essential that the equipment is visually inspected before each and every use. Further to this, a thorough inspection by the manufacturer or person deemed competent by the manufacturer is required at least every 12 months or in accordance with the manufacturer's instructions.

If any defects or damage to the product is observed the unit should be discontinued from use immediately and stored in such a way so that the equipment cannot be used. The manufacturer should then be contacted to see if the item can be repaired of if it should be permanently removed from service.

If there is any doubt as to the integrity of a deadweight anchor or if any damage to the unit is observed, do not use the equipment.

Do not use the equipment if is dirty or has come into contact with solvents, lubricants or other contaminants. Deadweight anchors use friction to arrest a load. Do not use a deadweight anchor if you feel this friction has been compromised in anyway.

Inspection records should be kept and made available to all persons using deadweight anchors.



5.2 DETAILED INSPECTIONS

These are the same as the pre-use checks carried out by a competent person at a set period (WAHSA recommends every 3 months). These checks must be documented and the documents kept.

5.3 INTERIM INSPECTION

These are additional detailed inspections. The need for and frequency of interim inspections will depend on the use and the environment. Examples of situations where they may be appropriate include: arduous working environments involving paints, chemicals, grit blasting operations and acidic or alkaline environments. The results of interim inspections should be recorded and kept.

6 LONGEVITY & OBSOLESCENCE OF DEADWEIGHT ANCHORS

Advice on obsolescence will be contained within the user instructions supplied by the manufacture. Deadweight anchors must not be used for periods which exceed the date given by the manufacturer. However, this lifespan may be significantly reduced dependent on working conditions. This reduced lifespan should be specified by a competent person. For detailed guidance on inspection procedures, see WAHSA PGN02.

7 CLEANING AND MAINTENANCE

Store the deadweight anchor in a dry, shaded, ventilated area away from direct heat.

8 STORAGE

Store the deadweight anchor in a dry, shaded, ventilated area away from direct heat.

9 RESCUE

A rescue plan should be formulated for the rescue of a person with the required equipment and trained personnel to carry it out. (See WAHSA PGN03)

10 TRAINING

WAHSA strongly recommend that all users of fall protection equipment are trained by a competent organisation. Training should include information on the selection of the correct products for intended work situation and pre-use checks for specific equipment.



11 USEFUL REFERENCE DOCUMENTS

The Work at Height Regulations 2005

BS 8437: 2005 Code of practice for selection, use and maintenance of personal fall protection systems and equipment for use in the workplace

BS EN 360: 2002 Personal protective equipment against falls from a height - Retractable type fall arresters

BS EN 362: 2004 Personal protective equipment against falls from a height - Connectors

BS EN 364: 2000 Personal protective equipment against falls from a height - Test methods

BS EN 365: 2004 Personal protective equipment against falls from a height - General requirements for instructions for use, maintenance, periodic examination, repair marking and packaging

BS EN 12275: 2013 Mountaineering equipment – Connectors – safety requirements and test methods.

INDG 367 Inspecting fall arrest equipment made from webbing or rope (HSE)

12 REFERENCES

BSI (British Standards Institution). 2012. BS EN 795: 2012. Personal fall protection equipment. Anchor devices. London: BSI.